



SWITCH OPTIONAL

33A (SINGLE/BUMP FIRE SWITCH)




ITEM	PART NO	DESCRIPTION
33A-1	DR0319R	O RING
33A-2	11003401	TRIGGER VALVE HEAD
33A-3	11006901	SPRING
33A-4	11003504	TRIGGER VALVE STEM
33A-5	DR2515H	O RING
33A-6	DR1119R	O RING
33A-7	11003803	TRIGGER VALVE GUIDE
33A-8	13907701	SINGLE/BUMP FIRE SWITCH
33A-9	PRO515R	PU RING
33A-10	13904501A	TRIGGER ASSEMBLY

34A (SINGLE FIRE SWITCH)



ITEM	PART NO	DESCRIPTION
34A-1	DR0319R	O RING
34A-2	11003401	TRIGGER VALVE HEAD
34A-3	11006901	SPRING
34A-4	11003504	TRIGGER VALVE STEM
34A-5	DR2515H	O RING
34A-6	DR1119R	O RING
34A-7	11003803	TRIGGER VALVE GUIDE
34A-8	13904501A	TRIGGER ASSEMBLY

35A (BUMP FIRE SWITCH)



ITEM	PART NO	DESCRIPTION
35A-1	DR0319R	O RING
35A-2	11003401	TRIGGER VALVE HEAD
35A-3	11006901	SPRING
35A-4	11003503	TRIGGER VALVE STEM
35A-5	DR2515H	O RING
35A-6	DR1119R	O RING
35A-7	11003803	TRIGGER VALVE GUIDE
35A-8	15104501A	TRIGGER ASSEMBLY